


MSD INSTALLATION INSTRUCTIONS

COIL, SINGLE TOWER, CPC IGNITION PN 8232

MSD PN 8232 - COIL WIRING

The MSD 8232 coil includes a pre-wired 3-pin connector.
Each of the wires must be connected securely.



PIN A: Connect to the common wire.

PIN B: Connect to the signal wire.

PIN C: Connect to a good engine ground.


M S D • WWW.MSDPERFORMANCE.COM • (9 1 5) 8 5 7 - 5 2 0 0
FRM 36423 © 2021 MSD LLC
Created 12/21

MSD INSTALLATION INSTRUCTIONS

COIL, SINGLE TOWER, CPC IGNITION PN 8232

MSD PN 8232 - COIL WIRING

The MSD 8232 coil includes a pre-wired 3-pin connector.
Each of the wires must be connected securely.



PIN A: Connect to the common wire.

PIN B: Connect to the signal wire.

PIN C: Connect to a good engine ground.

M S D • WWW.MSDPERFORMANCE.COM • (9 1 5) 8 5 7 - 5 2 0 0
FRM 36423 © 2021 MSD LLC
Created 12/21